



# TB Baseline

## Hardwood Flooring Installation Summary

Applicable to TB Baseline Collection Floors Only  
Applicable to floors purchased after 4-1-2020

This Summary is not meant to replace the applicable Installation Instructions. Please read and understand those instructions carefully.

**If at any time during the installation of this flooring you have a question or a concern, STOP and call Thomas Benjamin at 1-562-236-5744! Thomas Benjamin will only be held responsible for obvious issues in flooring that has not been installed.**

### Installation Summary

Permissible Installation Locations	Above Grade – On Grade – Below Grade
Permissible Installation Methods	Glue-down, Nail-down
Acclimation Period	<b>TB BASELINE FLOORS DO NOT REQUIRE ACCLIMATION. DO NOT OPEN CARTONS UNTIL READY TO BE INSTALLED.</b>
Environment	Permanent HVAC should be on and operational a minimum of 7 days and maintained between 60° and 80° F and a relative humidity of 35%- 55% prior to delivery, during, and after installation of the flooring.
Subfloor	The subfloor must be flat, meeting a minimum of 1/8" within 10'.
Raised Foundations	Basements and crawl spaces must be dry. Use of a 6 mil black polyethylene is required to cover 100% of the crawl space earth.
Tape	ScotchBlue™ Painter's Tape Delicate Surface #2080 ONLY (see Installation Instructions)
Installation over Radiant Heat?	Yes, refer to Installation Instructions
Staples / Cleats to be used	Recommended staple/cleat length is 1-1/2"
Wood subfloor - Nail-down Installations	MC not to exceed 12% and not more than 3% more or less than the wood flooring MC.
Expansion Gaps	Allow a minimum 1/2" (12 mm) expansion around all vertical obstructions. Large spans (> 20') may require Field Expansion. See Installation Instructions.
Nail-down Installations	Supplemental Adhesive Required. See Installation Instructions.

### Choosing the Correct Adhesive – Engineered Floors Only

Adhesive and Moisture Barrier Systems from the following manufacturers are permitted for the full-spread glue-down installation of Thomas Benjamin Floors:

**Bostik**

**Sika**

**Mapei**

**Franklin**

**Fortane**

Follow the Adhesive Manufacturer's Installation Instructions for the testing of subfloor moisture content. Choose an adhesive and (if necessary) moisture barrier system that is warranted by the adhesive manufacturer for installation under those circumstances. Thomas Benjamin will not be responsible for problems that might arise due to moisture transference from a subfloor to the hardwood flooring.

### Care – Maintenance – Environment

Failure to follow these guidelines may void applicable warranties.

In-home humidity level	The proper humidity level (35%-55% relative humidity) must be maintained within the space at all times during the year.
In-home temperature	Normal living conditions to be maintained at all times – between 60° and 80° F.
Wet- or damp-mopping	Never wet-mop, damp-mop, or clean your floor with water or other products
Cleaning product	Bona® Swedish Formula® Hardwood Floor Cleaner per instructions on the bottle
Full Care and Maintenance Instructions	Available on our web site <a href="http://www.tbflooring.com">www.tbflooring.com</a>